



FIX THE CABINET ANGLES WITH THE M6 SREW AND PLAIN WASHER (REFER TO THE SIDE IMAGE FOR ANGLES VALUE) SCREWD ON THE M6 LOWER INSERT.

