




DANCE FLOOR

High power sound system with subwoofer for Clubs and Disco.



ZONES	AMPLIFIER	POWER	OUT LINES	LOUDSPEAKERS	ZONES	ACCESSORIES
1	DMA 504	2 X 300 W @ 8 ohm	LOW IMP.	2 x COMPACT M 10	DANCE	1 X RC 401
		500 W @ 8 ohm	LOW IMP.	1 x S 15		

— Amplifier output
 — Audio input
 — Accessories
 — 4 channels audio bus
 — Mute from emergency system

RCF provides examples of typical applications using various products as a general guideline, not intended as a reference for installers.